

GOLD

Backed by the strength and stability of Toyota

# WHAT IS A VEHICLE SERVICE AGREEMENT (VSA)?

A VSA helps protect you from covered repair costs due to mechanical breakdown after your vehicle's warranty expires. We offer variable options to provide you the right level of protection, based on the mileage you drive and how long you plan to keep your vehicle.

# **GENERAL BENEFITS**<sup>1</sup>



Mechanical breakdown protection



24/7 roadside assistance



Substitute transportation



Travel protection



Transferable



Deductible options

## VEHICLE ELIGIBILITY

#### **NEW VEHICLE PLANS**

Toyota vehicles are eligible if less than three (3) years old from date vehicle was first put into service and up to 36,000 total vehicle miles.<sup>2</sup>

#### **USED VEHICLE PLANS**

Toyota vehicles are eligible within current model year plus nine (9) prior model years and up to 200,000 total vehicle miles. See your dealer for eligibility requirements. Used vehicle plans are available through your dealer **only** at the time of used vehicle purchase or lease.<sup>2</sup>

## **VSA GOLD WILL HELP YOU**

- Be prepared and protected after your vehicle's warranty expires
- Be protected against rising costs of labor and covered parts
- Ensure repairs are handled by a factory-trained service technician using only Toyota-approved parts
- Enjoy 24/7 roadside assistance
- Receive access to a network of Toyota dealers throughout the U.S. and Canada
- Be able to transfer your agreement one time at no additional cost, potentially increasing the resale value of your Toyota

#### Exclusions

- Any repairs/replacements made without prior authorization are excluded. Additional exclusions may apply. Please
  consult your customer product agreement for specific coverage details, including limitations and exclusions.
- 2. Time and mileage coverage periods for new vehicle plans are measured from date vehicle was first put into service as a new vehicle and zero miles. Time and mileage coverage periods for used vehicle plans are measured from the agreement application date and agreement application mileage. Coverage expires upon reaching the maximum time or mileage of the coverage period selected, whichever occurs first. Deductible applies to each eligible repair visit. See your agreement for complete terms, conditions, and restrictions.



## **VSA GOLD**

VSA Gold covers the cost of mechanical breakdown of the parts listed in GRAY and RED after your vehicle's warranty expires. Your vehicle's Limited Powertrain warranty covers those parts listed in GRAY text only.3

#### **ENGINE**

All internally lubricated components and: Balance Shaft; Camshaft; Crankshaft; Crankshaft Pulley; Cylinder Heads; Engine Block; Engine Mounts; Engine Oil Reservoir; Engine Oil Reservoir Pump; Equipment Drive Shaft; Exhaust Manifolds; Flexplate; Flywheel; Idler Pulley; Intake Manifold; Oil Pan; Oil Pressure Switch; Oil Pump; Oil Sending Unit; Piston; Seals and Gaskets; Supercharger; Supercharger Intercooler; Tensioners; Timing Belt; Timing Chain; Timing Cover; Timing Gears; Turbo Intercooler; Turbo Wastegate; Turbocharger; Valve Covers; Water Pump

#### **MANUAL TRANSMISSION**

Transfer Case Components (All internally lubricated components) and: Clutch Master Cylinder; Clutch Release Cylinder; Gears and Shafts; Hoses, Lines, and Tubes; Seals and Gaskets; Shift Linkage and Cables; Transfer/Transmission Case; Transmission Mounts; Shift Lever Knob

#### **AUTOMATIC TRANSMISSION**

Transfer Case Components (All internally lubricated components) and: Hoses, Lines, and Tubes; Seals and Gaskets; Shift Linkage and Cables; Solenoids; Torque Converter; Transfer/Transmission Case; Transmission Mounts; Vacuum Modulator; Shift Lever Knob

#### **AXLE ASSEMBLY**

(Front, Rear, 4WD and AWD): All internally lubricated components and: 4x4 Actuators; Axles and Bearings; Center Support Bearing; Constant Velocity Boot Band; Constant Velocity Joints and Boots; Differential Carrier Assembly; Drive Axle Housing; Drive Shaft; Hubs; Locking Hubs; Seals and Gaskets; Thrust Washers; Universal Joints; Viscous Coupling

#### **SUSPENSION**

(Front and Rear): Bushings/Bearings; Control Arm Shafts; Electronic Suspension Actuator/Motor and Compressor; Radius Arm; Spindle; Spindle Support; Steering Knuckle; Sway Bar Link; Upper and Lower Ball Joints; Upper and Lower Control Arms

#### STEERING

Gear Box internal components and: Bushings/Bearings; Center Link; Hoses, Lines, and Tubes; Idler Arm; Pitman Arm; Power Steering Pump; Power Steering Pump Pulley; Rack and Pinion; Seals and Gaskets; Steering Column; Steering Column Coupling; Steering Column Shaft; Steering Dampener; Steering Gear Box and Pump Housings; Tie Rod End

#### **FUEL SYSTEM**

Air Flow Meter; Carburetor; Diesel Fuel Injection Pump; Electric Fuel Pump; Electronic Fuel Injection System; Fuel Injectors; Fuel Pressure Regulator; Fuel Pump; Fuel Sending Unit; Fuel Sensors; Fuel Tank; Throttle Body

#### **COOLING SYSTEM**

Cooling Fan Relay; Cooling Fan Sensor; Engine Cooling Fan Motor; Engine Fan; Engine Fan Clutch; Engine Fan Motor; Engine Fan Shroud; Fan Bracket Subassembly; Radiator; Seals and Gaskets

### AIR CONDITIONING/HEATING

Air Conditioning Lines and Tubes; Air Conditioning Pressure Switches; Air Temperature Control Programmer; Blower Motor; Blower Motor Resistor; Compressor; Compressor Clutch

Assembly; Compressor Pulley; Condenser; Condenser Fan and Motor; Evaporator; Evaporator Temperature Sensor; Expansion Valve; Heater Control Head; Heater Control Valve; Heater Core; Idler Pulley; Pressure Regulator Assembly; Receiver/Dryer; Schrader Valve; Seals and Gaskets

Anti-Lock Braking/Traction Control Actuator, Pump and Motor; Brake Booster; Brake Hoses, Lines, and Tubes; Disc Brake Calipers; Load-Sensing Proportioning Valve; Master Cylinder; Parking Brake Cable; Proportioning Valve; Seals and Gaskets; Wheel Cylinders

#### **ELECTRICAL**

Alternator; Automatic-Off Headlamp Sensor, Timer and Switches; Automatic Shoulder Belt Motor and Switches; Automatic Temperature Control Unit; Blower Motor; Blower Motor Resistor; Clutch Starter Interlock Switch; Convertible Top Motor; Cruise Control Actuator/Servo; Cruise Control Sensors and Switches; Cruise Control Vacuum Motor; Defogger Relay; Distributor; Engine Cooling Fan Motor; Headlamp Washer; Ignition Coil; Lamp Failure Indicator Sensor; Manually Operated Switches; Power Antenna Motor and Cable; Power Door Lock Actuator; Power Mirror Defogger; Power Mirror Motor; Power Seat Motors; Power Sliding Door Motor; Power Window Motor/ Regulator; Retractable Headlamp Motor; Smart Entry and Start System Switch, Sensor and Electronic Control Unit; Starter Motor; Starter Solenoid; Stop Light Switch; Sunroof Motor; Windshield Washer Pump; Wiper Motor

## **COMPUTERS AND ELECTRONICS**

Anti-Lock Braking/Traction Control Computer and Sensors; Automatic Shoulder Belt Computer; Body Control Module; Cruise Control Computer; Electronic Ignition Unit; Electronically Controlled Transmission/Transfer Case Computer and Sensors; Electronically Modulated Suspension Computer; Engine Control Computer: Knock Sensor: Power Mirror Electronic Control Unit: Power Seat Computer; Progressive Power Steering Computer; Sunroof Control Computer and Relay; Tilt/Telescoping Steering Computer; Trip Computer; Vehicle Security Computers and Sensor; Wiper Module

## HYBRID/ALTERNATIVE FUEL



Actuator Assembly Shift Control; Hybrid Vehicle Generator Assembly; Hybrid Vehicle Motor Assembly; Hybrid Vehicle Transaxle Assembly; Transmission Input Damper Assembly; Battery Computer Assembly; Battery Current Sensor; Boost Charging Inlet and Plug-in Electronic Control Unit; Circuit Breaker Sensor; Combination Meter Assembly; Combination Meter Computer; Fuel Cell Water Pump; Fueling Receptacle; Hybrid Vehicle Battery Blower Assembly; Hybrid Vehicle Battery Blower Motor Control; Hybrid Vehicle Battery Thermistor; Hybrid Vehicle Control Computer; Hydrogen Pipes and Manifolds; Inverter Assembly with Converter; Main Switch Assembly; Power Source Control Computer Assembly; Power Steering Electronic Control Unit Assembly; Power Steering Gear Assembly; Pressure Sensors; Reducing Valve; Shift Lever Position Sensor; Skid Control Computer Assembly; Steering Column Assembly; Transmission Control Module

# **ADDITIONAL BENEFITS**

### 24/7 ROADSIDE ASSISTANCE

For those times when the unexpected might occur, VSA Gold also provides 24-hour roadside assistance.

- · Battery jump start
- · Lockout protection
- Delivery of up to three (3) gallons of fuel, no more than two (2) times per month<sup>4</sup>
- Tire Service Impaired tire will be replaced with your inflated spare
- Towing to the nearest authorized dealer<sup>4</sup>
- Winching Extrication from any ditch, mud, sand, or snow. Vehicle must be immediately adjacent to a regularly traveled road and capable of being serviced with standard servicing equipment.

#### TRAVEL PROTECTION

If you're unable to drive your vehicle due to the mechanical breakdown of a covered component, substitute transportation and travel protection benefits will provide reimbursements of:

- Up to \$35 per day for car rentals or other substitute transportation. 5 Maximum of five (5) days per occurrence.
- Up to **\$50 per day** for lodging and meals if you're more than 150 miles from home.<sup>5</sup> Maximum of four (4) days over the life of your agreement.

#### Exclusions

4. Excludes Fuel Cell and Electric vehicles, which may be towed to the nearest authorized Toyota servicing dealer or authorized fueling station. Fuel delivery will not apply.

5. Due to a covered mechanical failure. Valid receipts are required for all reimbursements.

The purchase of a Vehicle Service Agreement voluntary protection product is optional, cancelable (subject to specific agreement terms) and not required to obtain credit.

This brochure is intended as an outline of Vehicle Service Agreement coverage. Coverage is subject to exclusions and limitations set forth in the Vehicle Service Agreement. The actual coverage, exclusions, and limitations of the agreements issued to customers may vary both from state to state and according to the program features chosen by the customer. In certain states, Toyota Motor Services Company administers Vehicle Service Agreements. Vehicle Service Agreements are available through Toyota Financial Services at participating Toyota dealerships only. Not available in select states. This brochure is not applicable in Florida.

©2023 Toyota Motor Insurance Services, Inc. Lexus Financial Services is a service mark used by Toyota Motor Insurance Services, Inc. (TMIS) and its subsidiaries. Voluntary Protection Products are administered by TMIS or a third party contracted by TMIS.

00704 · 23-616253 (12/23)



